
IQ SmartPen SP200



Packing List:



Charging Base (USB Receiver) *1

Product Specifications:

Product Name: IQ SmartPen SP200 Pen Point: Compatible with infrared technology, 3mm pom

Data Transmission Mode: 2.4GHz RF Wireless Technology

Interface: Micro USB

Battery: Built-in 140mAh lithium battery


Operating Current: About 10mA Operating Distance: Within 15m

Operating System: Windows 7/8/10/11, Android Operating Voltage: USB-powered operation, 3.3-4.2V

Security Warning:

1.Do not use the product for children to play!
2.Do not disassemble the machine by non-profes sional personnel!

Product Illustration:



Functions Description:

Button	Operation	Windows
Q Button –	Click	Screenshot (Hyperlink)
	Long press	Annotation (Blackboard)
Key 4	Click	Previous page
	Long press	PPT presentation/exit (No Action)
Key 3	Click	Next page
	Long press	Return to desktop (No Action)
Key 2	Click	Left mouse click
	Double click	Mode Switch Mouse、Laser Spotlight、Magnifier (No Action)
	Long press	Move Pointer
Key 1	Click	Switch Color
	Long press	Eraser

Notes:

Different system/software support different key functions. For IQ OS & IQ KitsMemos & IQ JoinMemos & IQ ClassOne, please refer to related system or software user manual.

Operation Steps:

Install IQ SmartPen Driver for Windows in the CD or Download from the website:

https://www.igboard.net/ig-smartpen.php

- 2. Plug the USB receiver into the USB port.
- Press the smart pen button to use.

Operation Tips:

- 1. The reception distance of the receiver will be reduced by the interference of the surrounding electronic devices.
- 2. The machine automatically enters the power-saving mode when there is no operation. Do not need to shut down the machine during normal use.
- 3. Work instructions: the green light lights up when the button is pressed.
- 4. When charging, the red light is on, and when charging is completed, the green light is on.

Pairing Tips:

- 1. Press and hold Key1 and Key3 of IQ SmartPen at the same time, then plug the USB receiver into the USB port of Windows.
- 2.If the screen displays that the mouse moves up and down quickly and then remains stationary for 5 seconds, the USB receiver enters public mode.
- 3.Unplug the USB receiver, press and hold Key1 and Key4 of IQ SmartPen at the same time, and then plug the USB receiver into the USB port of Windows again.

 4.If the screen displays that the mouse moves up and down quickly and then remains stationary for 5 seconds, the USB receiver and the pen body are successfully paired operatoring.
- *IQ SmartPen & receiver are paired by default at the factory.

- IQ Board Australia
- 6 Lakewood Blvd, Carrum Downs Victoria, 3201 AUSTRALIA
- 472 627 (1300 IQBOARD)
- www.igboard.com.au
- enquiries@iqboard.com.au

Warranty Policy

Thanks for using IQ product. To obtain better warranty service, please carefully read the following clauses and keep this warranty card properly.

You should provide this warranty card for each warranty claim.

Duration of Warranty

- 1.We provide one-year warranty for IQ SmartPen. Please see the warranty documents and sales contract for details.
- 2.We do not replace or refund any sold product except for quality problem.

Disclaimers

- This warranty does not cover the following cases:
- 1. Man-made surface corruption, break, distortion, or damages due to improper installation, operation, and maintenance.
- 2. Connecting port is distorted or cracked.
- 3. Warranty period is expired.
- 4. Product repaired by unauthorized service provider or personnel, or disassembled by users themselves.
- The original label or bar code has been removed, damaged or modified.

Software upgrade

We provide free lifetime upgrade service for software applied on the IQ product you buy. But we charge for upgrade service for different hardware and accessorial function modules.

Returnstar Interactive Technology Group Co., Ltd. reserves the final interpretation and modification rights of this warranty.

Warranty Card

Product Name:
roduct Name:
Product Mode:
Dealer Name:
Dealer Tel:
Purchase Date:
Jser Name:
Maintenance Staff Signature:
Dealer Seal: